

TASK 1 - Basic

Cybersecurity Awareness & Security Audit

For this task I decided to use:

1. Local system
2. Brave browser
3. Windows Powershell

Step 1: Checking password practices on my own system.

I opened my browser's saved passwords list. Fortunately the passwords met the minimum criteria and were not reused anywhere else. All of the passwords contained random characters with no two same characters or characters in sequence (such as 123... or abc...).

Step 2: Checking system update status

I entered the below command to show 5 most recent security updates:

Get-HotFix | Sort-Object InstalledOn -Descending | Select-Object -First 5

```
Windows PowerShell
Copyright (C) Microsoft Corporation. All rights reserved.

PS C:\WINDOWS\system32> Get-HotFix | Sort-Object InstalledOn -Descending | Select-Object -First 5
```

Source	Description	HotFixID	InstalledBy	InstalledOn
N	Update	KB5120998	NT AUTHORITY\SYSTEM	8/31/2026 12:00:00 AM
N	Update	KB5120997	NT AUTHORITY\SYSTEM	8/28/2026 12:00:00 AM
N	Update	KB5122385	NT AUTHORITY\SYSTEM	8/28/2026 12:00:00 AM
N	Update	KB5054156	NT AUTHORITY\SYSTEM	10/18/2025 12:00:00 AM

```
PS C:\WINDOWS\system32>
```

If the last update is very old, this would lead to “system not updated regularly”. The system needs to be updated regularly to prevent any security risks.

Step 3: Checking for exposed/open ports

The command used in the powershell for this step is:

```
netstat -ano | findstr LISTENING
```

This lists the ports on my computer that are open and listening. Any expected ports that are not recognizable are marked as a finding worth investigating.

```
PS C:\WINDOWS\system32> netstat -ano | findstr LISTENING
TCP    0.0.0.0:135           0.0.0.0:*           LISTENING      1912
TCP    0.0.0.0:445           0.0.0.0:*           LISTENING      4
TCP    0.0.0.0:2869          0.0.0.0:*           LISTENING      4
TCP    0.0.0.0:5040          0.0.0.0:*           LISTENING      12240
TCP    0.0.0.0:5357          0.0.0.0:*           LISTENING      4
TCP    0.0.0.0:7680          0.0.0.0:*           LISTENING      23272
TCP    0.0.0.0:28414         0.0.0.0:*           LISTENING      29432
TCP    0.0.0.0:35474         0.0.0.0:*           LISTENING      23560
TCP    0.0.0.0:49664         0.0.0.0:*           LISTENING      1592
TCP    0.0.0.0:49665         0.0.0.0:*           LISTENING      1432
TCP    0.0.0.0:49666         0.0.0.0:*           LISTENING      2448
TCP    0.0.0.0:49667         0.0.0.0:*           LISTENING      4120
TCP    0.0.0.0:49672         0.0.0.0:*           LISTENING      5852
TCP    0.0.0.0:49684         0.0.0.0:*           LISTENING      1552
TCP    127.0.0.1:5354        0.0.0.0:*           LISTENING      6300
TCP    127.0.0.1:5939        0.0.0.0:*           LISTENING      7288
TCP    127.0.0.1:23435       0.0.0.0:*           LISTENING      2616
TCP    127.0.0.1:27015       0.0.0.0:*           LISTENING      6268
```

From the above screenshot, some of the ports are noted below:

Port	Services	Notes
135	Windows RPC	Standard
445	SMB (file sharing)	Only a risk, if I'm using a public network
2869	SSDP/UPnP device discovery	Standard
5040	Windows Connected Devices Platform	Standard
5357	Network device API	Standard
7680	Windows update delivery optimization	Standard

28414, 35474, 49664 - 49684	Windows RPC	Standard
-----------------------------	-------------	----------

Step 4: Checking Firewall and User Account Status

This is done to check whether the system's firewall is actually turned on, and whether you have unnecessary admin/guest accounts sitting around.

The commands that were run are:

Get-NetFirewallProfile | Select-Object Name, Enabled

Get-LocalUser | Select-Object Name, Enabled

Get-LocalGroupMember -Group "Administrators"

```
PS C:\WINDOWS\system32> Get-NetFirewallProfile | Select-Object Name, Enabled
```

```
Name      Enabled
----      -
Domain    True
Private   True
Public    True
```

```
PS C:\WINDOWS\system32> Get-LocalUser | Select-Object Name, Enabled
```

```
Name              Enabled
----              -
Administrator     False
CodexSandboxOffline True
CodexSandboxOnline True
DefaultAccount    False
Guest             False
[REDACTED]         False
USER              True
WDAGUtilityAccount False
WsiAccount        False
[REDACTED]         False
[REDACTED]         True
```

```
PS C:\WINDOWS\system32> Get-LocalGroupMember -Group "Administrators"
```

```
ObjectClass Name              PrincipalSource
-----
User [REDACTED] OFFICIAL\Administrator Local
User [REDACTED] OFFICIAL\USER      Local
```

Windows Firewall was found enabled for the Private and Public network profiles, which is the expected secure configuration.

The built-in Guest account was disabled, which is correct. However, the audit found 4 enabled local user accounts (CodexSandboxOffline, CodexSandboxOnline, USER) versus only 1 account (hidden) that appeared to be a standard named personal account, but was disabled.

Having multiple unclear/unused accounts enabled increases the attack surface, since each is a potential entry point for an attacker if compromised. It is recommended that any accounts not actively in use be disabled, and that all enabled accounts be reviewed.

Recommendations

- Enable automatic OS updates.
- Replace weak/reused passwords with a password manager and 12+ character passwords.
- Close/investigate unused open ports.

Conclusion

This audit identified issues of varying severity. Applying the recommendations above would reduce the attack surface of the tested system (local).